

Madel	Tall Version		
Model	2 Groups	☐ 3 Groups	
Dimensions (WxHxD)	29.9" x 21.5" x 25"	38.9" x 21.5" x 25"	
Weight	172 lb	207 lb	
Power Cord Plug	NEMA 6-30P	NEMA 6-50P	
Max Absorbed Power	4000 W	5400 W	
Voltage & Frequency	220 V / 60 Hz		

GENERA	LMACH	HINEE	NVIRON	MENT
---------------	--------------	-------	---------------	------

I he installation area is clean and clear of dust and tools. It is not located in an active construction zone.
☐ The counter accommodates the machine size and weight (check selected model).
An access hole has been pre-drilled in the counter for drainage and power in accordance with model installation template.
☐ Hole in counter is fitted with a collar to protect electrical cord, water line & drain tube.
Machine can safely be installed with minimum clearances of 3" from the back wall, 4" on each side and 12" on top.

ELECTRICAL REQUIREMENTS

Power outlet receptacle is NEMA 6-30P (2 groups models) or NEMA 6-50P (3 groups models)
☐ Dedicated electrical circuit meets the selected Giusta model power requirements.
☐ No extension cord or power strip on the circuit.

WATER SPECIFICATIONS

Pressure & Hardness	Water Network
Pressure is between 21.8 PSI & 116.0 PSI.	☐ The water network provides cold, drinkable tap water.
pH range is between 6.5 & 7.5.	☐ Dedicated 3/8" diameter water line.
☐ Hardness (TDS) is between 89 PPM & 142 PPM.	Shutoff valve with a 3/8" G male pipe fitting on machine's end.
Machine water line is equipped with softness/filtration s	system and descaling device.

HIGHLY RECOMMENDED: Connection to a floor drain in accordance with local health code.



